



HMGP-KT1016

Model A - without ABS/Model B - with ABS

Fitment Guide

Version 1.2N17

Items provided in kit

- HM GP-KT1016
 - HM GP-KT1016 SR loom
 - HM GP-KT1016 coil loom
 - USB programmer lead
 - USB storage key
-
- HMGP Config software
 - Latest Programme file for HMGP-KT1016
 - HMGP User Guide
 - HMGP-KT1016 Fitment Guide

Step 1: Installing the HMGP-KT1016 Coil Loom




Attach the HM coil loom to the coil with the loom provided.



Step 2:

Installing the HMGP-KT1016 SR Loom



Connect the HM SR loom to crank sensor plug.

Connect the HM SR loom to the rear wheel sensor.
(Slightly different for HMGP-KT1016B option.)

Step 3:

Installing the HMGP-KT1016

The HM GP shifter can now be fitted and connected into the bikes coil, speed and RPM looms. We advise that the Earth lead is connected to the negative terminal of the battery.

**If you have any questions or
require any help, please call our
tech team on;**

TEL: +44 (0)1795 429168

Email: info@hmquickshifter.com